


* Please understand key indicators & functions at the first operation.

FRONT PANEL & KEY FUNCTIONS



Key Name	Symbol	Descriptions
Enter Key & Save Key	ENT	1. In the measuring status, press this key can enter to parameter pages. 2. In the parameter setting, press this key can save the value & go to next parameter.
Shift Key & Alarm Setting Key	←	1. In the measuring status, press this key for 3 sec can enter to alarm setting page. (The selecting digit will be flashed) 2. In the parameter setting, press this key can move the cursor left.
Up Key & Display Span Adjusting Key	↑	1. In the measuring status, press this key for 3 sec can enter to display value adjustment of "SPAN" 2. In the parameter setting, press this key can increase the digits.
Down Key & Display Zero Adjusting Key	↓	1. In the measuring status, press this key for 3 sec can enter to display value adjustment of "ZERO" 2. In the parameter setting, press this key can decrease the digits.

- **1. The following block charts are parameters codes, parameter codes & parameters will alternate flashing if the parameters can be modified.
- 2. To modify the parameters, please press ← ↑ ↓, and press ENT to save the parameters after the modification.
- 3. Please don't forget the new pass code after modification.
- 4. In any pages, press ↑ & ↓, or don't press any keys for 2 minutes that will back to measuring status.

GENERAL MODE OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
Power On		Alarm Setpoint	
	Measuring Status	Present value for measurement.	
	Alarm (AL) Setpoint	Press ← ↑ ↓ to modify the alarm setpoint.	00000
		Display: "ZERO" & "SPAN" Adjustment	
	Measuring Status	Present value for measurement.	
	Display Span Adjustment (dSPAN)	Press ← to select adjusting speed rate, press ↑ ↓ to modify the span value. PS: To use this function to adjust the real span value.	00000
	Display (dZEro) Adjustment (dZEro)	Press ← to select adjusting speed rate, press ↑ ↓ to modify the zero value. PS: To use this function to adjust the real zero value.	00000
		Offset Adjustment	
	Measuring Status	Present value for measurement.	
	Offset Adjustment Setting (oFSt)	Press ← ↑ ↓ to modify offset value.	00000

ENGINEER LEVEL OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default	
	10000	Measuring Status Present value for measurement		
	P.Cod	Pass Code (P.Cod) Press ←↑↓ to enter pass code.	00000	
	P.Code Correct	Pass code is correct that will enter to parameter groups. Pass code is wrong that will back to measuring status.		
	SYS	System Setting Page (SYS)		
	tYPE	Sensor Type Setting (tYPE) The page shows temperature sensor's type.	Customers specify	
	dP	Decimal Point Setting (dP) Press ←↑↓ to select decimal point (0, 1) EX: if the value shows "0.0" that means the decimal point is 1 digit.	Customers specify	
	unit	Temperature Unit Setting (unit) Press ↑↓ to select the units (°C or °F).	Customers specify	
	CJC	Cold Junction Compensation (CJC) Press ↑↓ can switch (on) or (off) cold junction compensation.	no	
	AvG	Display Average Setting (AvG) Press ←↑↓ to modify display average (1~99) PS: Please use this function for stable display value when input signal is unstable.	00005	
	CodE	Pass Code Setting (CodE) Press ←↑↓ to modify pass code(0~19999) PS: Please don't forget the new pass code after modification.	00000	
	LoCK	Key Lock Setting (LoCK) Press ↑↓ to lock the keys, using key lock function only can view the parameters, but cannot modify any values. PS: no(unlock), YES("ENT" unlock, others lock)	no	
	Alarm Setting Group Procedures			
	roP	Alarm Setting Page (roP) The following steps are only available for alarm output.		
	ACtt	Alarm Action Setting (ACtt) Press ↑↓ to modify alarm value that is ≥(Hi) or <(Lo) for alarm action.	Customers specify	
P.b	Proportion Control Percentage (P.b) Press ←↑↓ to modify proportion control percentage(0~999).	00000		
C.time	Proportion Time (C.time) Press ←↑↓ to modify proportion time (0~99 sec).	00000		

Error Code of Self-Diagnosis

Display	Descriptions	Display	Descriptions
coFL	Cold junction is over sensor's (PT100) measuring range (0~100°C).	doFL	Input signal is over sensor's (T.C) measuring range.
-coFL	Cold junction is under sensor's (PT100) measuring range (0~100°C).	-doFL	Input signal is under sensor's (T.C) measuring range.
oPEr	Input signal or cold junction is disconnection.	E-00	EEPROM reading /writing suffers the interference (about 1 million times)

**Please check the wiring connection is correct first, if the problem still exist, please return the meter to the factory.

CALIBRATION OPERATING PROCEDURES

Block Charts	Display	Descriptions	Default
	10000	Measuring Status Present value for measurement Press ENT & ← together for 3 sec will enter to calibration operating procedures.	
	inLo	Input Low Scale Calibration (inLo) 1. Input standard low scale signal. 2. Press ←↑↓ to calibrate input low scale.	
	inHi	Input Hi Scale Calibration (inHi) 1. Input standard hi scale signal. 2. Press ←↑↓ to calibrate input hi scale.	
	SYS	System Setting Page (SYS) 1. Finish calibration operating procedures will enter to system setting group. 2. Press ↑ & ↓ together for 3 sec to back to measuring status.	

Warning: Calibration of this meter requires a standard signal with 0.01% accuracy or better and an external meter with 0.005% accuracy or better.